

Connection Pipework (obligatory required)

The Connection Pipework for Well Optimizer ECHO 1 (WOP E1) serves as standard connection for each WOP E1 unit. It provides each valve and instrument for a trouble-free start and shutdown.

The entry valve is used to cover the unit. The entry pipe is equipped with a pressure gauge for pressure monitoring. It has an additional valve for a simple pressure relief. The Connection Pipework is also equipped with a separate pressure gauge to monitor the pressure inside the Well Optimizer Echo 1.



Graphic: Connection Pipework for mounting the High Pressure Sensor Unit / Transducer
(Example Picture only)

Technical Data:

Medium:	Crude Oil incl. associated Gas & production water
Design Pressure:	5.000 psi
Operating Temperatures:	-40 / + 120°C at 5.000 psi
Ambient Temperature Outdoor:	min. / max. - 40°C / +60°C

On site it is just necessary to connect the wellhead and with the Connection Pipework. Connection with 1" NPT female thread (5.000 psi / 345 barg).
A sour gas configuration according to NACE MR0175 is available on request.

Note: A Connection Pipework is obligatory for running a WOP E1 unit. It can be provided by the buyer or can be ordered from the seller.